


(36)



FIG. 2



436




FIG. 4A




FIG. 4B





FIG. 4C








Fig.6C





Loads and runs Agent from harddisk.


Fig. 7A


Fig. 6D
















FIG. 8D





F16.8F

FIG. 9: 4




FIG. JOA






FIG. /08










Fig. II.C.





6

93

FIG 13A




FIG. 13B




FIG.14A




FIG.14B




FIG.14C





FIG.14D






FIG.I4F1
Detailed "Agent" Work Cycle





FIG./4G

ModemCall 138 139 Use First Dial String In Dial String Table Table 142 -Send Dial String Abort No Received Received NO Received CONNECT? DIAL TONE? **BUSY?** Yes Line Busy Redial Immediately Line In Use Sleep y Seconds 148 Received Abort Server Query 151 Send Serial Number 153 152 Send Received Serial Number Server "ACK"? I Times? **Process Received** Disconnect, Cleanup and State Back To Alert Command Unhook Port Disconnect; Cleanup and **Unhook Port** State Back To Active

FIG.14H



//////

Agent Code

FIG. 15






FIG. 15A











Fig. 19


。"我你看到我






. 4 - - 34







TOROT IT IS




Fig. 23